


S



## UNLOADING POINT FOR PLASTIC PACKAGING

Stora Enso Ingerois Oy



**S** = Unloading point

Gate address: **Etelätie 3, 46900 Inkeroinen**

Logistics supervisor's phone number: **+358 400 806 679**

Shift foreman's phone number: **+358 400 543 944**

Process operators's phone number: **+358 40 182 5590**

## Unloading instructions for driver:

1. Entry to the mill area via the main gate, and driving route to the unloading area and out as indicated on the above map. The provided driving routes must be strictly adhered to.
2. Before entering the mill site, contact the logistics supervisor (tel. +358 400 806 679) who will arrange for the process operator to arrive.
3. **The driver is absolutely forbidden to access the mill facilities!**
4. Make sure that the unloading point is clean and tidy.

## GENERAL SAFETY INSTRUCTIONS:

- In addition to the personal protective equipment prescribed by the hauling company, wear safety shoes, a helmet or bump cap, protective eyewear and high-visibility clothing.
- Follow the instructions of the haulier.
- The speed limit at the mill site is 40 km/h unless a lower speed limit is indicated by traffic signs.
- Smoking is prohibited at the mill site.



**IN CASE OF EMERGENCY, CALL THE EMERGENCY NUMBER 112 AND INFORM THE MILL'S MAIN GATE OF THE EMERGENCY CALL, TEL. +358 20 462 6502.**  
**IN CASE OF A HAZARDOUS SITUATION, IMMEDIATELY CONTACT THE SHIFT FOREMAN, TEL. +358 400 543 944.**